

GDP 2400, GDP 3300

Software-Update:

1. Downloaden der Upgrade-Software

- Kopieren Sie die Datei "gdp2400_Vxxx.exe" oder "gdp3300_Vxxx.exe auf das Laufwerk Ihres PCs und führen Sie das sich selbst entpackende Programm aus.

2. Erstellen der Upgrade-Software

- Verwenden Sie nur neue CD-ROM-Rohlinge (keine CD-Roms verwenden die schon einmal gelöscht wurden).
- Der CD-Name ist frei wählbar (wir empfehlen den aktuellen Versionsstand und Gerätetyp als CD-Namen zu verwenden).
- Brennen Sie die Datei "**bank30.rom**" in die oberste Ebene (Stammverzeichnis) der CD. Der Dateiname "**bank30.rom**" darf nicht verändert werden. Eine Änderung des Dateinamens kann beim Ladevorgang zum Ausfall des DVD-Players führen.

3. Software-Upgrade in den DVD-Player laden

- Schublade öffnen durch Drücken der Taste "OPEN/CLOSE".
- Software-Upgrade-CD einlegen und Schublade schließen durch Drücken der Taste "OPEN/CLOSE".
- Nach dem Einlesen des Software-Upgrade gibt das Gerät die Software-Upgrade-CD automatisch aus, schaltet sich Aus und wieder Ein.
- Software-Upgrade-CD entnehmen.

Achtung: Versuchen Sie nicht den Ladevorgang durch Drücken einer Funktionstaste am DVD-Player oder über den Fernbediener abubrechen oder sogar den DVD-Player vom Netz zu trennen. So sind eventuell die Gerätefunktionen und ein Neustart der Upgrade-Funktion nicht mehr gewährleistet.

Gewährleistung

Wir weisen ausdrücklich darauf hin, dass nur von GRUNDIG freigegebene Betriebssoftware für die DVD-Player zulässig ist. Wird bei Reklamationen festgestellt, dass eine aus nicht legitimierten Quellen stammende Betriebssoftware in die Geräte geladen wurde und deswegen das Software-Upgrade fehl schlug, wird dies als Fremdeingriff bewertet. Dies führt zum Erlöschen jeglicher Gewährleistungsansprüche. GRUNDIG muss daher alle aus diesen Gründen resultierenden Kostenerstattungen generell ablehnen. Instandsetzungskosten, auch innerhalb der Gewährleistungszeit, gehen in diesen Fällen stets zu Lasten des Endkunden. Wir weisen darauf hin, dass die Software urheberrechtlich geschützt und nur für den eigenen Bedarf bestimmt ist. Gegen Zuwiderhandlungen wird rechtlich vorgegangen.

GDP 2400, GDP 3300

Software-Update:

1. Downloading the upgrade software

- Copy the "gdp2400_Vxxx.exe" or gdp3300_Vxxx.exe file on the disk drive of your PC and run this self-unpacking programme.

2. Creating the upgrade software

- Use only new blank CD-ROMs (never use CD-ROMs which have already been erased).
- You may select any name for the CD (we recommend to use the current software version and the unit's type name as CD name).
- Copy (burn) the "**bank30.rom**" file into the uppermost level (root directory) on the CD. The file name "**bank30.rom**" must not be changed. Changing the file name may lead to a failure of the DVD player during copying.

3. Loading the software upgrade into the DVD player

- Open the CD tray by pressing the "OPEN/CLOSE" button.
- Insert the software upgrade CD then close the CD tray by pressing the "OPEN/CLOSE" button.
- When reading of the software upgrade is completed, the software upgrade CD is automatically ejected and is switching OFF and now ON.
- Remove the software upgrade CD.

Attention: During software loading it may happen that the "CD" symbol remains visible or that random characters appear in the display. If this is the case do not try to abort loading by pressing a function button on the DVD player or on the remote control, or even by disconnecting the DVD player from the mains. In doing so the unit's functions or a restart after the upgrade procedure are no longer guaranteed.

Warranty

We expressly draw your attention to the fact that only operating software which has been released by GRUNDIG is allowed to be used with the DVD players. If, in the case of complaints, we find out that operating software from not legitimated sources has been loaded into the player and that the software upgrade has failed for this reason, this is considered as foreign intervention. This leads to the expiration of any guarantee claims. For this reason, GRUNDIG must generally reject any reimbursements of costs resulting from the above stated infringements. Repair costs, even those occurring within the guarantee period, are always at the charge of the end user.

We draw your attention to the fact that the software is protected by copyright and that it is determined for your personal use only. Legal actions will be taken in the event of violations.