

Operating Instructions DSR 3410 Serial Software Update Tool

Requisites:

Required components (hardware / software):

- Windows-PC
- Serial 1-to-1 RS232 cable (connectors: 9-pin, male – female)
- Loader-Software „DSR3410Loader.zip“
- Update-Software „DSR3410_V####.zip“

Installation:

Please copy the 2 ZIP-archives to an empty directory and extract all files.
(The loader-executable has to be started from within this directory).

Update Procedure:

Switch off the DSR 3410 (Mains switch!).
Disconnect all cables (Antenna, TV, VCR, ...).
Connect PC and DSR 3410 using the RS232 cable described above.
Connect the DSR 3410 mains cable and power-on the receiver.

Start the loader-executable „DSR3410Loader.exe“.
Select the serial port of the DSR 3410 connection.
Start the update by activating the button <Start Update>.
Please wait until the transfer of all 3 files (out.app, font.app und chlist.app) has been completed and the message „Update successfully completed!“ is displayed.

Switch off the DSR 3410 again (Mains switch!) and disconnect the RS232 cable.

Important note:

***Please do not switch off the DSR 3410 before the message „Update successfully completed!“ is displayed!
Following a premature interrupt of the update procedure the DSR 3410 may be inoperable!
In this case, please restart the update procedure from the beginning.***

For additional information please contact the Grundig customer service.

Your Grundig Team