

Operating Instructions DSR5450 HD - USB Download Software

Requisites

- Windows®-PC (Win-98, Win-ME, Win-2000, Win-XP)
- USB cable A-B (DSR5450 HD accessory)
- USB Driver and Download Software "DSR5450_USB_Downloader.zip"

Features

- Software Update
- Download MP3 or Photo ("*.jpg", "*.bmp") file(s) to DSR5450 HD
- Upload Audio or Video recordings from DSR5450 HD
- Download PVR recordings to DSR5450 HD

Installation


- 1 Copy "DSR5450_USB_Downloader.zip" to an empty directory and extract all files from the archive.
- 2 Power-on the DSR5450 HD.
- 3 Connect the USB cable.
- 4 Install the driver-software following the instructions of the „New Hardware“-Wizzard. Specify the subdirectory "...\\drivers\\win98_2000" of the unzip-directory ("...\\drivers\\winxp" for Win-XP) as driver location.
- 5 After successful installation You will find "HD STB USB" in the „USB-Controller“-List of the „Device Manager“

For additional information please contact the Grundig customer service.

Your Grundig Team


Software Update

1. Turn on the DSR5450 HD.
2. Connect USB cable between PC and DSR5450 HD.
3. Start USB downloader (Double-click on "USB Downloader.EXE").
4. Select DSR5450 update software (e.g. "DSR5450_HD_QPSK_V108_041122w.bin").
5. Click the "Download" button
6. Wait until the progress bar reaches 100% and the message: "Download completed" is displayed




Download MP3 and Photo files

1. Select MP3 or Photo files that you want to download to the DSR5450 HD (You can select multiple files at a time).
2. Select the DSR5450 HD FAV group.
3. Click the "Download" button
4. Wait until the downloading completes.



Upload Audio / Video recordings from DSR 5450 HD

1. Select **"Video"** (at bottom of USB Downloader window; see screenshot below).
2. Select the target folder for the DSR 5450 recordings.
3. Select the DSR5450 recording(s) for upload (right hand selection box).
4. Press the "Upload" button
5. Wait until the uploading completes.



Download Audio / Video recordings to the DSR5450 HD

1. Select **"Video"** (at bottom of USB Downloader window; see screenshot above).
2. Select the AV-file(s) for download to the DSR 5450 HD (left hand file selection box).
3. Press the "Download" button
4. Wait until the downloading completes.